

menus

NATTOU

1

4 sec



→



2

+CLIC 1x



→



3

+CLIC 1x



→



4

+CLIC 1x



→




5

CLIC 5x

10 sec

15 min




→



on/off

NATTOU



charge



USB



Battery XH8502540 3.7V
+500mAh 201808

WARNING: Not suitable for children under 36 months due to small removable parts.

